



TR 200

mancal tipo FLANGE
serviço NORMAL



Caixa	Eixo		Dimensão nominal (mm)								Paraf.	Peso (kg)		D	Rolamentos			
	Ø pol	Ø mm	a	e	p	i	g	l	s	b		YTR2 YTR2T	GTR2		Y 200 / Y 200 T		G 200	
														z1	B1	z2	B2	
TR 203 ⁽¹⁾	1/2 5/8	12 15 17	81	65,9	76,1	17,0	11	28	11,5	31	M10 3/8	0,40	-	40,0	33,0	22,0	-	-
TR 204	3/4	20	92	77,5	89,5	19,0	11	31	11,5	35	M10 3/8	0,70	0,80	47,0	37,3	31,0	45,5	43,5
TR 205	7/8 15/16 1	25	97	83,1	96,0	19,0	12	32	11,5	36	M10 3/8	0,80	0,80	52,0	38,7	34,0	45,9	44,3
TR 206	1-1/16 1-1/8 1-3/16 1-1/4	30	117	100,5	116,0	20,0	12	32	11,5	44	M10 3/8	1,00	1,10	62,0	42,2	38,1	50,1	48,3
TR 207	1-1/4 1-5/16 1-3/8 1-7/16	35	128	112,3	129,7	21,0	15	33	14,0	48	M12 1/2	1,60	1,70	72,0	46,4	42,9	53,3	51,1
TR 208	1-1/2	40	137	121,2	140,0	24,0	13	38	14,0	51	M12 1/2	1,80	2,00	80,0	54,2	49,2	58,9	56,3
TR 209	1-9/16 1-5/8 1-11/16 1-3/4	45	150	138,6	160,0	24,0	14	38	14,0	55	M12 1/2	2,20	2,40	85,0	54,2	49,2	58,9	56,3
TR 210	1-13/16 1-7/8 1-15/16 2	50	150	138,6	160,0	28,0	18	42	14,0	55	M12 1/2	2,50	2,70	90,0	60,6	51,6	66,1	62,7

(1) - montado com rolamento B 203 V22 FRM em lugar de Y 200 V22 FRM